## **DC 50 Fridge Operating Tips**

Although the fridges are recommended by us here at Jay Wolfe, the installation book supplied with these fridges is vague. Please see some additional operational tips below to guide you how to use them correctly.

When initially powered up the control panel will illuminate and you are able to choose between 0 and 10 on the display using the arrows, 0 being the coldest and 10 being the highest setting. Once you have selected the number you require, the control panel will flash to confirm your selection then the display will go off to save energy.

The fridge will then run until the internal temperature matches the setting you selected previously. Once it gets to temperature the fridge will turn itself off and when required turn itself back on again to keep the internal temperature as you selected.

If you press the left hand button again the display will illuminate and the number shown will be current internal temperature inside the fridge.

It is generally considered that setting 0-3 will make and keep ice, however there are numerous variations that can effect it such as ambient temperature, battery level, how much food is in the fridge & how often the door is opened.